





CHIP 'N DIP


Obtain the dish that is to hold the dip in the centre of the Chip 'n Dip. Then find an appropriate piece of wood. The diameter of the wood should be about three times the diameter of the dip holding bowl.





Mount the wood on a broad faceplate. Ensure that the screws are into wood which will be removed later.



Shape the bottom. The foot may be made taller than for a normal bowl to aid the lifting of the fully loaded Chip 'Dip off the table. Make a spigot for a broad chuck for safety and an accurate re-mount. Sand and finish the area outside the bowl foot.



Re-mount on a chuck. Clean the face. Cut the cavity to fit the dip dish. The rim of this cavity should be lower than the rim of the glass or ceramic dish that will fit into it and lower than the outer rim of the Chip 'n Dip. Hollow the chip area. Finish all these surfaces.



Re-mount on a vacuum chuck, Cole jaws, or pressed to a faceplate. Clean off the bottom. Sand and finish.